







Wohnung	21 re	21 li
Aufstockung	060.602	060.601




Zeile 2


Übersicht Wohnungen Eingang 21 Aufstockung

Massstab 1:250





Wohnung	21 re	21 mi	21 li
EG	060.003	060.002	060.001
1.OG	060.103	060.102	060.101
2.OG	060.203	060.202	060.201
3.OG	060.303	060.302	060.301
4.OG	060.403	060.402	060.401
5.OG	060.503	060.502	060.501





Zeile 2

Übersicht Wohnungen Eingang 21

EG – 5.OG

Massstab 1:250





Zeile 1

Zeile 2

Zeile 3

Zeile 4




Wohnung	23 re	23 li	25 re	25 li	27 re	27 li	29 re	29 li
Aufstockung	070.402	070.401	080.402	080.401	090.402	090.401	100.402	100.401

Zeile 2

Übersicht Wohnungen Eingang 23– 29 Aufstockung

Masstab 1:250

0 2 5 10




Zeile 1

Zeile 2

Zeile 3

Zeile 4



Wohnung	23 re	23 li	25 re	25 li	27 re	27 li	29 re	29 li
EG	070.002	070.001	080.002	080.001	090.002	090.001	100.002	100.001
1.OG	070.102	070.101	080.102	080.101	090.102	090.101	100.102	100.101
2.OG	070.202	070.201	080.202	080.201	090.202	090.201	100.202	100.201
3.OG	070.302	070.301	080.302	080.301	090.302	090.301	100.302	100.301

Zeile 2

Übersicht Wohnungen Eingang 23 – 29 EG – 3.OG

Masstab 1:250

0 2 5 10

